

**DRY
ULTRASONIC
POWDER**



American Solutions
ULTRASONIC TANK CLEANER

**DRY
ULTRASONIC
POWDER**

PRODUCT INFORMATION

Dry Ultrasonic Powder is specifically formulated for the quick removal of films and camouflage. This product is a high alkaline cleaner. It is an extra strength, fast acting cleaner for use in the printing industry. Formula 731 is especially formulated to penetrate and remove the heaviest buildup of films and camouflage on anilox rolls. Restore anilox rolls to original specifications and significantly improves color and density. Eliminates the cost of returning anilox rolls for recoating due to plugged cells.

CAUTION

- ◆ Harmful if swallowed
- ◆ Avoid contact with skin or eyes
- ◆ Keep out of the reach of children
- ◆ For commercial, industrial and institutional use by trained personnel only

MADE IN THE USA

EMERGENCY & FIRST AID PROCEDURES:

EYES: Immediately flush eyes with water for 15 minutes, holding the lids apart to insure flushing of entire eye.

SKIN: Flush affected area with large amounts of water for 15 minutes. Remove contaminated clothing and shoes.

INGESTION: Give large quantities of water. Follow with citric fruit juice. Call physician immediately.

DIRECTIONS: For in ALL ultrasonic Equipment. Suggested dilution 1/2lb to be added to 5 gallons of water for normal cleaning/ 1lb to 5 gallons of water for heavy cleaning. **NOTE: The use of hot water accelerates the cleaning action.** For best results, rotate anilox continuously while in bath for 15 to 30 minutes depending on degree of contamination. After removal from ultrasonic tank, rinse thoroughly with running tap water. Wipe Dry.

*Health-2 Flammability-0 Reactivity-0 Personal-B