

ULTRASONIC FORMULA

731



American Solutions

Heartland Metal Safe Solutions

REMOVES INK & GREASE FROM WASHABLE SURFACES

ULTRASONIC FORMULA

731

PRODUCT INFORMATION

Anilox Roll Concentrate: Fast, Economical, Non-Flammable, Non-Combustible, Non-Fuming, Pleasant Odor

Formula 731 is specifically formulated for the quick removal of films and camouflage. This product is a high alkaline cleaner. It is an extra strength, fast acting cleaner for use in the printing industry. Formula 731 is especially formulated to penetrate and remove the heaviest buildup of films and camouflage on anilox rolls.

Restores anilox rolls to original specifications and significantly improves colors and density. Eliminates the cost of returning anilox rolls for recoating due to plugged cells.

CAUTION

- ◆ Contains strong alkalis
- ◆ Harmful if swallowed; Avoid contact with skin or eyes
- ◆ Keep out of the reach of children
- ◆ Store above 40 degrees Fahrenheit; If product freezes, allow to thaw, then mix well before use
- ◆ Avoid splashing of concentrated liquid when drawing off supply; Protective gloves and goggles are recommended.
- ◆ For commercial, industrial and institutional use by trained personnel only

MADE IN THE USA

EMERGENCY & FIRST AID PROCEDURES:

EYES: Immediately flush eyes with water for 15 minutes, holding the lids apart to insure flushing of entire eye.

SKIN: Flush affected area with large amounts of water for 15 minutes. Remove contaminated clothing and shoes.

INGESTION: Give large quantities of water. Follow with citric fruit juice. Call physician immediately.

DIRECTIONS: Use in ALL ultrasonic equipment. Suggested dilution of 5 parts water to 1 part Formula 731. **Note: The use of hot water accelerates the cleaning action.** For best results, rotate anilox continuously while in bath for 15 to 30 minutes depending on degree of contamination. After removal from ultrasonic tank, rinse thoroughly with running tap water. Wipe dry.

Health-2 Flammability-0 Reactivity-0 Personal-B